

3 PHASE MOTOR WIRING

On your motor terminal block, there are terminals marked U1, V1 and W1. The cables can be hooked to these in any order, but we suggest you do both motors the same. If any motor needs to be reversed to match the controls on the front panel, simply swap positions of any 2 wires.

